



ASSEMBLY INSTRUCTIONS

- 1 CUT OUT SMALL BODY TUBE MARKING GUIDE, TAPE AROUND TUBE AND MARK OFF SPACES FOR FIN PATTERN "A".
- 2 USING TEMPLATES, MARK & CUT OUT FINS "A" & "B" (4-EACH)
 AND TAPER LEADING EDGES.
- 3 GLUE FINS "A" FLUSH WITH END OF BODY TUBE.
- 4 SLIP FIN RING OVER FINS "A", ADD GLUE FILLET TO BOTH SIDES OF FINS.
- 5 CUT OUT LARGE TUBE MARKING GUIDE, TAPE AROUND TUBE AND MARK OFF SPACES FOR FINS "B". THESE MARKS SHOULD LINE UP WITH FINS "A". SEE PLAN VIEW FOR ALIGNMENT.
- 6 GLUE FINS "B" TO FIN RING. CHECK ALIGNMENT WITH FINS "A".
- 7 GLUE LAUNCH LUG FLUSH WITH END OF BODY TUBE.
- 8 CUT TWO SLOTS 1/4" APART 1-INCH FROM FRONT OF BODY TUBE, INSERT SHOCK CORD THRU SLOTS AND ADD GLUE.
- 9 GLUE SCREW EYE TO NOSE CONE.
- 10 TIE SHOCK CORD AND STREAMER TO SCREW EYE.
- 11 APPLY RING OF GLUE WITH A STICK 2 1/2"INTO REAR OF BODY TUBE. INSERT ENGINE BLOCK & WIPE OFF EXCESS GLUE.

PARTS LIST

1 - NOSE CONE

1 - STREAMER MATERIAL

1 - BODY TUBE

i i

1 - LAUNCH LUG

1 - FIN RING TUBE

1 - FIN SHEET

1 - SCREW EYE

1 - ENGINE BLOCK

1 - SHOCK CORD WADDING REQUIRED - NOT FURNISHED IN KIT



