

Tiffany Hobbies of Ypsilanti

PK-205



RECOMMENDED MOTORS

F25-6W, F80-5, G25-5W, G40-7W, G80-7, G125-10, H55-10W, H90-10W

Approximate Weight Length

10 oz. 43 in.

Diameter 1.5 in.



29mm motor mount w/24mm adapter Aircraft grade five ply plywood fins Plastic nose cone High strength body tube 18" ripstop nylon parachute with hardware 1/4" launch lug Shockcord

This near minimum diameter rocket is capible of exeeding MOCK ONE. Features 18" parachute, 29mm motor mount, and a 29mm to 24mm motor mount.

ASSEMBLY INSTRUCTIONS

Thank you for purchasing the Wasp model rocket kit. We hope that you will have many enjoyable hours flying your new Tiffany Hobbies rocket kit.

Please read these instructions before assembling, so that you will become familiar with how the kit is to be assembled.

Before assembling, check the kit for completeness. This kit should contain the following parts:

- (1) BT-1.52-34 Body tube
- (1) LL-.25 Launch lug
- (2) CR1-1.52-1.14 Centering rings
- (1) P-18 Parachute
- (1) Shock cord mount

- (1) MT-1.14 Motor mount tube
- (1) PNC-1.52 Nose cone
- (3) Plywood fins
- (1) Shock cord
- (1) Motor adapter

NOTE: If any parts are missing or damaged, please contact us before assembling the kit.


To complete the kit you will need the following items:

5 minute Epoxy Sanding sealer Ruler Sandpaper (80, 220, and 400) Cyanoacrylate Adhesive Sharp modeling knife Sanding block


ASSEMBLY


- 1) Round the leading and trailing edges of each fin with 80 grit sandpaper on a sanding block. Fine sand the entire fin smooth with 220 grit sandpaper.
- 2) Cover the fin mount tab with masking tape so that the sanding sealer won't seep onto the area to be glued. Seal the fins with sanding sealer, lightly sanding between coats. This will fill the grain of the plywood to obtain a smooth finish.
- 3) Epoxy the two centering rings flush with each end of the motor mount tubes, and with the shock cord mount extending away from the motor mount assembly.

- 4) With a sharp knife cut out the fin slots. The fin slots are marked out on the body tube.
- 5) You must check the fit of the motor mount before gluing. To do this, insert the motor mount into the back end of the body tube where the fin slots have been cut. If the fit is too tight, sand the centering rings until a smooth fit is obtained. Then epoxy the motor mount into the body tube so that the bottom centering ring is flush with the end of the body tube and the shock cord mount extends to the top of the body tube.



6) Epoxy the fins into the fin slots in the body tube. Make sure they are straight with the body tube. For maximum strength give the fins a good fillet coat of epoxy.






9) Tie the shock cord to the mount on the nose cone. Apply a drop of cyanoacrylate adhesive on the knot. Attach the parachute to the nose cone.

10) Check the fit of the nose cone into the body tube. If the cone is too loose, wrap tape around the cone. If the cone is to tight, sand it down to a nice smooth fit.

11) Paint the rocket in your choice of colors.



PREPARING FOR FLIGHT

1) Place a generous amount of recovery wadding in the body tube. Slide the wadding down into the body tube (do not pack the wadding).

2) Fold the parachute and insert it into the body tube. Slide the nose cone into the body tube.

3) Wrap 1/2" masking tape around the nozzle end of the motor so that the diameter is equal to the outside diameter of the motor tube. Friction fit the motor into the motor tube.

FLYING INSTRUCTIONS

- 1) Always follow motor manufacturers instructions when preparing and flying this rocket.
- 2) Always follow all local laws and ordinances when flying.
- 3) F.A.A. approval may be required to fly this rocket.

THOY

TIFFANY HOBBIES OF YPSILANTI P.O. BOX 467, YPSILANTI, MI 48197 PHONE/FAX 313-741-0847